



Maß: (tolerance) Geräte: (tools)

	SP 49 S 200 RS 200	SP 49 S 270 RS 165 S 200 SPS360	SP 35 S 140 S 200 S 270	SP 60 S 200 RS 200	SP 60 S 270 RS 165 S 200 SPS360	SP 60 S 200 RS 200	SP 60 S 270 RS 165 S 200 SPS360	SP 60 S 270 RS 165 RS 170 SPS400	SP 80 S 270 RS 165 S 200 SPS360	SP 80 S 270 RS 165 RS 170 SPS400
A	140	140	140	140	140	140	140	140	140	140
B	140	140	140	140	140	140	140	140	150	150
C	115	115	115	100	100	100	100	100	100	100
D	115	115	115	100	100	100	100	100	100	100
E	30	15	30	0	0	0	0	0	0	0
F	15	15	15	0	0	0	0	0	0	0
G	90	90	90	75	75	75	75	75	75	75
H	50	50	50	35	35	35	35	35	35	35
I	31	31	16	16	16	16	16	16	76	76
J	90	90	105	105	105	105	105	105	105	105
K	35	35	20	35	35	35	35	35	35	35
L	46	46	16	76	76	76	76	76	16	16

AEND.-NR.: 08064 GEZ.:JAU GES.: JSC
 AEND.DATUM:08.07.08 DAT.:15.05.06

FREIMASSTOLERANZEN (GENERAL TOLERANCES)	LAENGENMASS (LENGHT)mm TOLERANZ (TOLERANCE)mm	... 50	50...250	250...1000	1000...	WINKELMASS (ANGLE) TOLERANZ (TOLERANCE)	...180°
		±1,5	± 2,0	± 3,0	± 5,0		±10°